

P 17 Tempra IP 44 – ELV 16 i 32 A

gniazda i wtyczki przemysłowe na napięcie 20/25 V~



0552 06



0552 45



0552 21


Dane techniczne **str. 330**

Gniazda wtyczkowe stałe

Pak.	Nr ref.		
5	16 A 0552 06	32 A 0552 56	2P 20/25 V~

Gniazda wtyczkowe tablicowe

5	16 A 0552 45	32 A 0552 95	2P 20/25 V~
---	-----------------	-----------------	--------------

Wtyczki przenośne

5	16 A 0552 21	32 A 0552 71	2P 20/25 V~
---	-----------------	-----------------	--------------

Gniazda wtyczkowe przenośne


5	16 A 0552 31	32 A 0552 81	2P 20/25 V~
---	-----------------	-----------------	--------------

Wtyczki odbiornikowe

5	16 A 0552 41	32 A 0552 91	2P 20/25 V~
---	-----------------	-----------------	--------------

P 17 Tempra Pro IP 66/67 – 16 i 32 A

gniazda i wtyczki przemysłowe



5554 58



5553 28


Dane techniczne **str. 331**

Gniazda wtyczkowe stałe

Dwa kąty montażowe (5° lub 25°)

Pak.	Nr ref.		
5	16 A 5553 54	32 A 5554 54	200/250 V~ 2P+Z
5	5553 55	5554 55	3P+Z
5	5553 56	5554 56	3P+N+Z
5	5553 58	5554 58	380/415 V~ 3P+Z
5	5553 59	5554 59	3P+N+Z

Gniazda wtyczkowe tablicowe

Montaż na pokrywach zestawów zasilających lub puszek

5	16 A 5553 84	32 A 5554 84	200/250 V~ 2P+Z
5	5553 85	5554 85	3P+Z
5	5553 86	5554 86	3P+N+Z
5	5553 88	5554 88	380/415 V~ 3P+Z
5	5553 89	5554 89	3P+N+Z

Gniazda wtyczkowe przenośne

Dostarczane odblokowane

5	16 A 5553 04	32 A 5554 14	200/250 V~ 2P+Z
5	5553 05	5554 15	3P+Z
5	5553 06	5554 16	3P+N+Z
5	5553 08	5554 18	380/415 V~ 3P+Z
5	5553 09	5554 19	3P+N+Z

Wtyczki przenośne

Dostarczane odblokowane

5	16 A 5553 24	32 A 5554 34	200/250 V~ 2P+Z
5	5553 25	5554 35	3P+Z
5	5553 26	5554 36	3P+N+Z
5	5553 28	5554 38	380/415 V~ 3P+Z
5	5553 29	5554 39	3P+N+Z

Wtyczki odbiornikowe

5	16 A 0568 03	32 A 0568 23	200/250 V~ 2P+Z
---	-----------------	-----------------	-----------------